



**BACnet Enabler
(BlackSite)
User Manual**

Contents

1. Introduction.....	3
2. System requirements	4
3. Connecting the network.....	5
4. Downloading the BACnet Enabler software	6
5. Installing the BACnet Enabler software	6
6. Updating XLE freezers.....	10
6.1 Starting the BACnet Enabler software.....	10
6.1.1 Licenses	11
6.2 Selecting the freezer(s) to update	12
6.2.1 Manual IP entry.....	12
6.2.2 Finding freezers on the network	12
6.3 Starting the upload process.....	14
6.3.1 Upload started.....	14
6.3.2 Upload finished	15
7. Support.....	16

1. Introduction

Thank you for using the BACnet Enabler software. The BACnet Enabler will allow you to update existing Stirling Ultracold XLE freezer to provide BACnet/IP connectivity.

To complete the installation and configuration, basic computer knowledge is necessary. If you are an unexperienced user, please refer to a professional. Read this manual thoroughly and carefully! The following instructions are essential for the installation and configuration of your BACnet Enabler software and XLE freezer:



It is strongly recommended to pay attention to all instructions marked with this symbol, because these are necessary for an error-free functioning of your BACnet Enabler software.



This symbol indicates background information.

Important information:

This documentation and all associated programs (software) are copyrighted. Stirling Ultracold grants the non-exclusive right to use the solely in object code format delivered software. The license holder is only allowed to copy the software once as a backup copy.

Stirling Ultracold reserves all rights that are not stated explicitly. Without former written permission and aside from cases regulated by law, neither this documentation nor the software must be

- duplicated, distributed, or made publicly available in any form
- edited, disassembled, reverse engineered, translated, decompiled or in any other form entirely or partly opened and in the following not duplicated, distributed, or made publicly available in any form

This documentation and the software were created with highest carefulness and inspected towards their correctness using state-of-the-art technology. Stirling Ultracold takes no guarantee or responsibilities whatsoever for the quality, performance, or marketability of the product for a certain purpose that differs from the scope of work given in the product description. The license holder is solely responsible for all risks or quality losses that may occur during the use of the product.

Stirling Ultracold is only responsible for disadvantages that result directly or indirectly from the use of the software, as well as random damages or consequential damages in case of intention or gross carelessness.

For the loss or damaging of hardware, software or data that occurred due to direct or indirect faults or destruction as well as for the costs (including telecommunication costs) that arose in connection with the documentation or the software and for faulty installations that were not done by Stirling Ultracold, all liability claims are explicitly excluded. The information included in this documentation and within this software can be changed without prior announcement because of technical progress.

January 2021

2. System requirements

Hardware:

- Pentium® or AMD® processor above 1 GHz or compatible
- At least 2 GB RAM
- 4 GB free hard disk space
- Graphics card capable of 1024*768 resolution

Software:


- Microsoft Windows
- Java Runtime Environment (included in installation package)

Network:

- Standard TCP/IP network
- DHCP server
- Both XLE freezer as well as computer running the BACnet Enabler connected to the same network

3. Connecting the network

Before running the BACnet Enabler, please make sure to connect both the XLE freezer as well as your computer to a network with DHCP server:




4. Downloading the BACnet Enabler software

Please use this link to download the latest revision of the BACnet Enabler.

[http://download.magnumes.net/Stirling/BACnetEnabler\(BS\)_Setup.exe](http://download.magnumes.net/Stirling/BACnetEnabler(BS)_Setup.exe)


If this link does not work, please copy it into the address bar of your internet browser:



This will start the download.

5. Installing the BACnet Enabler software


After the download is finished, you will find the Installer file in your Download directory:




To start the installation, please double-click on the file.

Depending on the Windows version you might get some warning message upon installation:



Please click on "More info"




And then on "Run anyway"



Lastly please click on "Yes"




If you're running a 64 Bit operating system, the installer will ask whether you would like to install the 64 Bit version of the BACnet Enabler:




It is suggested to use the 64 Bit version of BACnet Enabler with a 64 Bit operating system, so please click on "Yes".

This will start the BACnet Enabler Setup Wizard:




To continue the installation process, please click on "Next"

In the next screen, please carefully read and agree to the license agreement and click on “Next”:



Next please select the Destination folder and click “Install”:




This concludes the installation. Please click on “Finish”:




6. Updating XLE freezers

6.1 Starting the BACnet Enabler software

To start the BACnet Enabler software please double-click on the icon on the desktop and confirm the warning message with "Yes"




This will start the BACnet Enabler:



6.1.1 Licenses

To upgrade an XLE freezer you need a valid license for this freezer. To receive a valid license for your system, please provide the System ID to your Stirling sales representative:



With this System ID, Sterling will be able to generate a valid license and send you a Sterling license file.




Please copy this file to your personal directory.


Next, please click on "load license" in your BACnet Enabler:



This will open the File selector window:



Please select the license file and click on "Open". This will load the licenses to BACnet Enabler:




6.2 Selecting the freezer(s) to update

To upgrade an XLE freezer, the BACnet enabler software needs to know the IP address of the freezer. There are two ways to introduce a freezer to the BACnet enabler:

6.2.1 Manual IP entry


If you already know the IP address of the XLE to be updated and you only want to update a single freezer, you manually enter the IP address:



6.2.2 Finding freezers on the network


In case you do not know the IP address of the XLE or if you would like to update multiple freezers at once, you can search for available freezers on the network.

First, please select the network adapter that is being used to connect to the network from the drop-down menu:




Depending on your computer system used, there might only be one network adapter available.

To start the network search, please click on "Find":




This will start the network search:




⚠ The network search might take a while.

Once the process is finished, you will get a list of all the found XLEs on the network:




Please select all freezers to be updated:




6.3 Starting the upload process

To start the upload process, please make sure all the freezers to updated are marked and then click the upload button:




6.3.1 Upload started

Once the upload is started, the BACnet enabler will go through a few steps to transfer, activate and enable the new firmware. This will take a while.



6.3.2 Upload finished

When the upload is finished, you will get a status report:



GREEN
= upload OK
RED
= upload failed

Status report

7. Support

To get support for the BACnet Enabler, please contact:

Stirling Ultracold
6000 Poston Road
Athens, OH 45701

Business Hours: Monday through Friday 8:00 AM – 5 PM, Eastern Time USA

Phone:

Toll-Free: 855.274.7900

Phone: 740.274.7900

Fax: 740.274.7901

Email:

customerservice@stirlingultracold.com